

# Optivizor Regular Snout Sizing Charts

Use these 2 charts to size Regular Snout dogs


If you are between 2 sizes, then pick the smaller size.

Steps: 1) Head Measurement 2) Then Canine Weight

## 1) HEAD MEASUREMENT

(Reference Inches or Centimeters)

		7.5-11	11-13	13-15	15-18	18-21	21-24	25 +	Centimeters
		3-4	4.3-5	5-6	6-7	7-8.3	8.3-9.4	9.5 +	Inches
OPTIVIZOR SIZE	Mini								
	Toy								
	Small								
	Small Medium								
	Medium								
	Large								
	X Large								



Measure from Nose Tip to Mid Point behind ears.

## 2) CANINE WEIGHT

(Reference Weight in Kilograms and Pounds)

		1-2	2-6	5-12	10-25	23-35	33-45	46 +	Kilograms
		< 6	4-13	11-26	22-55	50-77	72-99	100 +	Pounds
OPTIVIZOR SIZE	Mini								
	Toy								
	Small								
	Small Medium								
	Medium								
	Large								
	X Large								

**\*\* Our sizing chart is a guide only \*\* \*\* It does not constitute a guarantee as to the fit of the Optivizor/Novaguard \*\***