- Head Circumference is !CRITICAL! measurement to help ensure correct OptiVizor sizing.
- Make sure to go over the MID-BASE of Ears, with the Ears laid flat against the head snug. (see pic)
- 3 Accurately Measure Twice, Order Once!
- Best to use soft tape measure. If you don't have one, use a string. Then put the string on a ruler to get the circumference measurement.







NOTE: Each size is color-coded as noted below. Requesting a size be in a different color is not available.

Optivizor Short Snout Sizing Charts



^{**} Our sizing chart is a guide only **

CLarge

^{**} It does not constitute a guarantee as to the fit of the Optivizor/Novaguard **