

<b>SOFT SHELL VEST WOMEN'S 5819</b>	<b>XS</b>	<b>S</b>	<b>M</b>	<b>L</b>	<b>XL</b>	<b>2XL</b>	<b>TOLERANCE</b>
<b>BODY LENGTH</b> measure from CB neck	23½	24	24½	25¼	26	26¾	½ +/-
<b>ACROSS SHOULDER</b>	14	14½	15	15¾	16½	17¼	½ +/-
<b>CHEST WIDTH</b> measure from 1" below armhole	18½	19½	20½	22	23½	25½	½ +/-
<b>BOTTOM OPENING WIDTH RELAXED 1/2</b>	19½	20½	21½	23	24½	27	½ +/-

**KEY TO COMMONLY ABBREVIATED SPEC INFORMATION (ALL MEASUREMENTS ARE IN INCHES)**

**CB** = CENTER BACK

**CHEST 1 INCH DOWN** = MEASURE THE FRONT OF THE GARMENT 1 INCH DOWN FROM THE ARMHOLE

**1/2** = MEASURE ONLY THE FRONT OF THE GARMENT, THEN DOUBLE THAT MEASUREMENT TO GET THE TOTAL CIRCUMFERENCE

**RELAXED** = DO NOT STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, SIMPLY LEAVE THE ELASTIC RELAXED AND MEASURE

**STRETCHED** = STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, MEASURE STRETCHED

