

<b>CLASSIC SOFT SHELL VEST MEN'S 9819</b>	<b>S</b>	<b>M</b>	<b>L</b>	<b>XL</b>	<b>2XL</b>	<b>3XL</b>	<b>TOLERANCE</b>
<b>BODY LENGTH</b> measure from CB neck	27	28	29	29 ¾	30½	31 ¼	½ +/-
<b>ACROSS SHOULDER</b>	17½	18	18 ½	19 ½	20 ½	21 ½	½ +/-
<b>CHEST WIDTH</b> measure from 1" below armhole	22 ¼	23 ¼	24 ¼	26 ¼	28 ¼	30 ¼	½ +/-
<b>BOTTOM OPENING WIDTH RELAXED 1/2</b>	21½	22½	23½	25½	27½	29½	½ +/-

**KEY TO COMMONLY ABBREVIATED SPEC INFORMATION (ALL MEASUREMENTS ARE IN INCHES)**

**CB** = CENTER BACK

**CHEST 1 INCH DOWN** = MEASURE THE FRONT OF THE GARMENT 1 INCH DOWN FROM THE ARMHOLE

**1/2** = MEASURE ONLY THE FRONT OF THE GARMENT, THEN DOUBLE THAT MEASUREMENT TO GET THE TOTAL CIRCUMFERENCE

**RELAXED** = DO NOT STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, SIMPLY LEAVE THE ELASTIC RELAXED

**STRETCHED** = STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, MEASURE STRETCHED