

BELLBOOT™ SIZING GUIDE

Measure for an Accurate Fit

Measuring around the horse's hooves will ensure the most accurate fit. However, if you are unsure of sizing, please contact your designated EquiFit sales representative or EquiFit for more assistance.



EquiFit BellBoot Size Chart

Sizes	Top Circumference	Bottom Circumference	Height
Small	7.50"	15.50"	4.25"
Medium	8.50"	16.75"	4.50"
Large	9.75"	18.75"	4.75"
X-Large	11.25"	20.50"	4.75"
XX-Large	12.50"	22.50"	5.00"

