

AXIS SOFT SHELL JACKET MEN'S 9317	S	M	L	XL	2XL	3XL	TOLERANCE
BODY LENGTH measure from neck (CB neck)	28	29	30	30 ¾	31 ½	32 ½	½ +/-
SHOULDER TO SHOULDER	17 ¼	17 ¾	18 ¼	19 ¼	20 ¼	21 ¼	½ +/-
CHEST WIDTH 1 inch below armhole	21 ¾	22 ¾	23 ¾	25 ¾	27 ¾	29 ¾	½ +/-
BOTTOM OPENING WIDTH RELAXED 1/2	21 ¼	22 ¼	23 ¼	25 ¼	27 ¼	29 ¼	½ +/-
SLEEVE LENGTH FROM CB short	33 ½	35	36 ¼	36 ¾	37 ¼	37 ¾	½ +/-

KEY TO COMMONLY ABBREVIATED SPEC INFORMATION (ALL MEASUREMENTS ARE IN INCHES)

CB = CENTER BACK

CHEST 1 INCH DOWN = MEASURE THE FRONT OF THE GARMENT 1 INCH DOWN FROM THE ARMHOLE

1/2 = MEASURE ONLY THE FRONT OF THE GARMENT, THEN DOUBLE THAT MEASUREMENT TO GET THE TOTAL CIRCUMFERENCE

RELAXED = DO NOT STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, SIMPLY LEAVE THE ELASTIC RELAXED

STRETCHED = STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, MEASURE STRETCHED



CHARLES RIVER APPAREL